



INQUIRIES?

PHONE 1.810.629.6663 | FAX 1. 810.629.8145
 WEB ATLASTECHNOLOGIES.COM
 EMAIL SALES@ATLASTECHNOLOGIES.COM
 ADDRESS 3100 COPPER AVE, FENTON, MI 48430

PRODUCT DETAILS

Shovel Stops & Traps

Features & Benefits

- Large family of stamped steel standard shovel stops and shovel traps.
- Shovel stops and traps are designed to fit the part contour by utilizing the integrated slots in the box and spade shovels for mounting and adjustment.
- Shovel stops and traps have integrated nuts to simplify adjustment.
- Shovel stops and traps are black oxide coated to prevent rust.
- Versatile scissor shovel may be used as a one piece shovel and trap combination or rotated 90 degrees for a side guide and trap.

Shovel Stops and Traps

Part Number	Component
S.125.AA.146	Shovel Trap
S.125.AC.131	Shovel Stop - 38 mm (1.5 in.)
S.125.AA.147	Scissor Shovel



Part#S.125.AA.146



Part#S.125.AC.13



Part#S.125.AA.147

ADDITIONAL TOOLING COMPONENTS INCLUDE:

Adapters, Adapter Brushings, Cross Bars, Edge Sensing Assemblies, Internal Wedges, Mounting Assemblies, Offsets, Shovels, Shovels & Traps, Standard Tooling Bases, Swivel Clamp Assemblies, Tooling Arms, Tooling Links, Universal Tooling Receivers